

How to use the oboe tip cutter

Related products : Oboe tip cutter




Image 1




Image 2



Warning

Never touch the cutting edge of the knife because it can cause injury.

How to position the reed

1. Position reed holder base block [1-1] with reference surface [2-1] at the value of scale [2-2] that corresponds with the length of the reed you want.
2. Tighten clamp screw [1-2].
3. Place reed [1-3] under knife [1-4].
4. Move the reed against the reference surface.



Note

If you take the reed holder out of the tip cutter, turn it 180°, and put it back, you can use the tip cutter for reeds with brass tubes like cor anglais reeds.




Image 3




Image 4

How to cut the tip

1. Put the tip cutter on a flat surface and hold it with one hand while pressing the reed on the reed holder base block with the index finger.
2. Put the index finger and thumb of the other hand on position A of lever set [3-1] and position B of knife set [3-2].
3. Cut the tip by making a pinch movement with the index finger and thumb till the lever set and knife set are in the position as shown in image 4.