Supported Printers

The application supports the below range of printers. If you do not find the relevant printer in the list, many other printers are indirectly supported by creating your own Printer Profile, or by printing to a hot-folder.

- Canon BJ-W3000
- Canon BJ-W3050
- Canon BJ-W7000
- Canon iPF500
- Canon iPF510
- Canon iPF600
- Canon iPF605
- Canon iPF610
- Canon iPF650 (qualified with Plain Paper and Coated Paper only)
- Canon iPF655 (qualified with Plain Paper and Coated Paper only)
- Canon iPF670
- Canon iPF671
- Canon iPF680
- Canon iPF681
- Canon iPF685
- Canon iPF686
- Canon iPF700
- Canon iPF710
- Canon iPF720
- Canon iPF750 (qualified with Plain Paper and Coated Paper only)
- Canon iPF755 (qualified with Plain Paper and Coated Paper only)
- Canon iPF760
- Canon iPF765
- Canon iPF770
- Canon iPF771
- Canon iPF780
- Canon iPF781
- Canon iPF785
- Canon iPF786
- Canon iPF810 (qualified with Plain Paper and Coated Paper only)
- Canon iPF815 (qualified with Plain Paper and Coated Paper only)
- Canon iPF820 (qualified with Plain Paper and Coated Paper only)
- Canon iPF825 (qualified with Plain Paper and Coated Paper only)
- Canon iPF830
- Canon iPF831
- Canon iPF840
- Canon iPF841
- Canon iPF850
- Canon iPF851
- Canon iPF5000
- Canon iPF5100
- Canon iPF6000S
- Canon iPF6100
- Canon iPF6200
- Canon iPF6300
- Canon iPF6350
- Canon iPF6300S
- Canon iPF6400
- Canon iPF6400E
- Canon iPF64x0S
- Canon iPF64x0SE

- Canon iPF6450
- Canon iPF8000
- Canon iPF8000S
- Canon iPF8100
- Canon iFP8300
- Canon iPF8300S
- Canon iPF8310
- Canon iPF8310S
- Canon iPF8400
- Canon iPF84x0S
- Canon iPF84x0SE
- Canon iPF9000
- Canon iPF9000S
- Canon iPF9100
- Canon iPF9400
- Canon iPF9400S
- Canon W6200PG
- Canon W6400D
- Canon W6400PG
- Canon W7200
- Canon W8200
- Canon W8200PG
- Canon W8400
- Canon W8400D
- Canon W8400PG
- Canon W8400PG
- Canon PRO-1000
- Canon PRO-2000
- Canon PRO-4000
- Canon PRO-6000
- Canon PRO-500
- Canon PRO-520
- Canon PRO-540
- Canon PRO-540S
- Canon PRO-560S
- Canon PRO-4000S
- Canon PRO-6000S
- Canon TM-200
- Canon TM-205
- Canon TM-300
- Canon TM-305
- Canon TM-5200
- Canon TM-5205
- Canon TM-5300
- Canon TM-5305
- Canon TX-2000
- Canon TX-3000
- Canon TX-4000
- Canon TX-5200
- Canon TX-5300
- Canon TX-5400
- Encad NovaJet 500
- Encad NovaJet 630
- Encad NovaJet 700
- Encad NovaJet 750
- Encad NovaJet 850

- Encad NovaJet 1000i
- Encad NovaJet PRO 600e
- Encad NovaJet PRO
- Encad NovaJet PROe
- Epson Stylus Pro 4400
- Epson Stylus Pro 4800
- Epson Stylus Pro 7000
- Epson Stylus Pro 7400
- Epson Stylus Pro 7600
- Epson Stylus Pro 7700
- Epson Stylus Pro 7710
- Epson Stylus Pro 7800
- Epson Stylus Pro 7880
- Epson Stylus Pro 7880C
- Epson Stylus Pro 7890
- Epson Stylus Pro 7900
- Epson Stylus Pro 7910
- Epson Stylus Pro 9000
- Epson Stylus Pro 9400
- Epson Stylus Pro 9600
- Epson Stylus Pro 9700
- Epson Stylus Pro 9710
- Epson Stylus Pro 9800
- Epson Stylus Pro 9880
- Epson Stylus Pro 9880C
- Epson Stylus Pro 9890
- Epson Stylus Pro 9900
- Epson Stylus Pro 9910
- Epson Stylus Pro 10000
- Epson Stylus Pro 10600
- Epson Stylus Pro 11880
- Epson Stylus Pro 11880C
- Epson SureColor SC-P6000
- Epson SureColor SC-P7000
- Epson SureColor SC-P8000
- Epson SureColor SC-P9000
- Epson SureColor SC-T3000
- Epson SureColor SC-T3050
- Epson SureColor SC-T3070
- Epson SureColor SC-T3080
- Epson SureColor SC-T3200
- Epson SureColor SC-T3200D
- Epson SureColor SC-T3250
- Epson SureColor SC-T3250D
- Epson SureColor SC-T3270
- Epson SureColor SC-T3270D
- Epson SureColor SC-T3470
- Epson SureColor SC-T5000
- Epson SureColor SC-T5050
- Epson SureColor SC-T5070
- Epson SureColor SC-T5080
- Epson SureColor SC-T5100
- Epson SureColor SC-T5200
- Epson SureColor SC-T5200D
- Epson SureColor SC-T5250
- Epson SureColor SC-T5250D

- Epson SureColor SC-T5270
- Epson SureColor SC-T5270D
- Epson SureColor SC-T5400
- Epson SureColor SC-T5470
- Epson SureColor SC-T7000
- Epson SureColor SC-T7050
- Epson SureColor SC-T7070
- Epson SureColor SC-T7080
- Epson SureColor SC-T7200
- Epson SureColor SC-T7200D
- Epson SureColor SC-T7250
- Epson SureColor SC-T7250D
- Epson SureColor SC-T7270
- Epson SureColor SC-T7270D
- Gestetner GWD2004
- Gestetner GWD2006
- Gestetner SP W2470
- HP DesignJet 70
- HP DesignJet 90
- HP DesignJet 110
- HP DesignJet 111
- HP DesignJet 120
- HP DesignJet 130
- HP DesignJet 500 (HP-GL/2)
- HP DesignJet 500PS (HP-GL/2)
- HP DesignJet 510 (HP-GL/2)
- HP DesignJet 510PS (HP-GL/2)
- HP DesignJet 750C
- HP DesignJet 800
- HP DesignJet 800PS
- HP DesignJet 1050C
- HP DesignJet 1055CM
- HP DesignJet 2000CP
- HP DesignJet 2500CP
- HP DesignJet 3000CP
- HP DesignJet 3500CP
- HP DesignJet 4000
- HP DesignJet 4000ps
- HP DesignJet 4020
- HP DesignJet 4020ps
- HP DesignJet 4500
- HP DesignJet 4500mfp
- HP DesignJet 4500ps
- HP DesignJet 4520
- HP DesignJet 4520mfp
- HP DesignJet 4520ps
- HP DesignJet 5000
- HP DesignJet 5000PS
- HP DesignJet 5100
- HP DesignJet 5100PS
- HP DesignJet 5500
- HP DesignJet 5500PS
- HP DesignJet D5800
- HP DesignJet D5800PS
- HP DesignJet T120
- HP DesignJet T520 24in

- HP DesignJet T520 36in
- HP DesignJet T610
- HP DesignJet T610ps
- HP DesignJet T620
- HP DesignJet T620ps
- HP DesignJet T730
- HP DesignJet T770
- HP DesignJet T770ps
- HP DesignJet T770 24
- HP DesignJet T770ps 24
- HP DesignJet T790
- HP DesignJet T790ps
- HP DesignJet T795
- HP DesignJet T795ps
- HP DesignJet T830 MFP
- HP DesignJet T920
- HP DesignJet T920ps
- HP DesignJet T930
- HP DesignJet T930ps
- HP DesignJet T1100
- HP DesignJet T1100ps
- HP DesignJet T1120
- HP DesignJet T1120mfp
- HP DesignJet T1120ps
- HP DesignJet T1200
- HP DesignJet T1200ps
- HP DesignJet T1300
- HP DesignJet T1300ps
- HP DesignJet T1500
- HP DesignJet T1500ps
- HP DesignJet T1530
- HP DesignJet T1530ps
- HP DesignJet T2300
- HP DesignJet T2300ps
- HP DesignJet T2500
- HP DesignJet T2500ps
- HP DesignJet T2530
- HP DesignJet T2530ps
- HP DesignJet T3500
- HP DesignJet T3500ps
- HP DesignJet T7100
- HP DesignJet T7100ps
- HP DesignJet T7200
- HP DesignJet T7200ps
- HP DesignJet Z2100
- HP DesignJet Z2110
- HP DesignJet Z2600
- HP DesignJet Z2600ps
- HP DesignJet Z3100
- HP DesignJet Z3100ps
- HP DesignJet Z3200
- HP DesignJet Z3200ps
- HP DesignJet Z5200
- HP DesignJet Z5200ps
- HP DesignJet Z5400
- HP DesignJet Z5400ps

- HP DesignJet Z5600
- HP DesignJet Z5600ps
- HP DesignJet Z6100
- HP DesignJet Z6100ps
- HP DesignJet Z6200
- HP DesignJet Z6200ps
- HP DesignJet Z6600
- HP DesignJet Z6600ps
- HP DesignJet Z6800
- HP DesignJet Z6800ps
- HP PageWide XL 4000
- HP PageWide XL 4000 MFP
- HP PageWide XL 4000PS
- HP PageWide XL 4000PS MFP
- HP PageWide XL 4500
- HP PageWide XL 4500 MFP
- HP PageWide XL 4500PS
- HP PageWide XL 4500PS MFP
- HP PageWide XL 5000
- HP PageWide XL 5000 Blueprinter
- HP PageWide XL 5000 MFP
- HP PageWide XL 5000PS
- HP PageWide XL 5000PS Blueprinter
- HP PageWide XL 5000PS MFP
- HP PageWide XL 5100
- HP PageWide XL 5100 MFP Blueprinter
- HP PageWide XL 5100 MFP
- HP PageWide XL 5100PS
- HP PageWide XL 5100PS MFP Blueprinter
- HP PageWide XL 5100PS MFP
- HP PageWide XL 6000
- HP PageWide XL 6000PS
- HP PageWide XL 8000
- HP PageWide XL 8000 Blueprinter
- HP PageWide XL 8000PS
- HP PageWide XL 8000PS Blueprinter
- HP DesignJet T1700
- HP DesignJet T1700 Postscript
- HP DesignJet T1700dr
- HP DesignJet T1700dr Postscript
- HP DesignJet T1708
- HP DesignJet T1708dr
- HP DesignJet Z6
- HP DesignJet Z9
- HP DesignJet Z6610
- HP DesignJet Z6810
- Imagio MP W3600
- Imagio MP W2400
- Lanier LP124w
- Lanier LW324
- Lanier LW326
- Mutoh RJ-900C
- Mutoh RJ-901C
- Mutoh RJ-900X
- Mutoh RJ-901X
- Mutoh RJ-4000

- Mutoh RJ-4100
- Mutoh RJ-8000
- NRG MP W2400
- NRG MP W3600
- NRG SP W2470
- Océ 535X-42
- Océ 535X-60
- Océ 535X-600-42
- Océ 535X-600-60
- Océ ColorWave 300
- Océ ColorWave 500
- Océ ColorWave 550
- Océ ColorWave 600
- Océ ColorWave 650
- Océ ColorWave 700
- Océ ColorWave 810
- Océ ColorWave 900
- Océ ColorWave 910
- Océ ColorWave 3500
- Océ ColorWave 3700
- Océ ColorWave 9000
- Océ CS5050
- Océ CS5070
- Océ PlotWave 300
- Océ PlotWave 340
- Océ PlotWave 345
- Océ PlotWave 350
- Océ PlotWave 360
- Océ PlotWave 365
- Océ PlotWave 450
- Océ PlotWave 500
- Océ PlotWave 550
- Océ PlotWave 750
- Océ PlotWave 900
- Océ TCS300
- Océ TCS400
- Océ TCS500
- Océ TDS300
- Océ TDS320
- Océ TDS400
- Océ TDS450
- Océ TDS600
- Océ TDS700
- Océ TDS750
- Océ TDS800
- Océ TDS860
- Ricoh Aficio MP W2400
- Ricoh Aficio MP W3600
- Ricoh Aficio SP W2470
- Ricoh CW2201SP
- Ricoh W6700SP
- Ricoh W7100 PS
- Ricoh W8140 PS
- Roland Hi-Fi JET FJ-40
- Roland Hi-Fi JET FJ-50
- Roland Hi-Fi JET FJ-540

- Roland Hi-Fi JET FJ-740
- Savin 2404WD
- Savin 2404WDP
- Savin 2406WD
- Seiko LP-1010
- Selex SG-950T
- Xerox 6204
- Xerox 8825
- Xerox 8830