Supported Printers

The application supports the below range of printers.
If you do not find the relevant printer in the list, many other printers are indirectly supported by creating your own Printer Profile, or by printing to a hot-folder.

Series	Specific Models
Canon BJ	Canon BJ-W3000 Canon BJ-W3050 Canon BJ-W7000
Canon iPF	Canon iPF500 Canon iPF510 Canon iPF600 Canon iPF605 Canon iPF610 Canon iPF650 Canon iPF655 Canon iPF670 Canon iPF671 Canon iPF680 Canon iPF681 Canon iPF685 Canon iPF686 Canon iPF700 Canon iPF710 Canon iPF720 Canon iPF750 Canon iPF755 Canon iPF760 Canon iPF765 Canon iPF770 Canon iPF771 Canon iPF780 Canon iPF781 Canon iPF785 Canon iPF786 Canon iPF810 Canon iPF815 Canon iPF820 Canon iPF825 Canon iPF830 Canon iPF831 Canon iPF840 Canon iPF841 Canon iPF850 Canon iPF851 Canon iPF5000 Canon iPF5100 Canon iPF6000S Canon iPF6100 Canon iPF6200 Canon iPF6300 Canon iPF6300S Canon iPF6350 Canon iPF6400 Canon iPF6400E Canon iPF6400S Canon iPF6400SE Canon iPF6410S Canon iPF6410SE Canon iPF6450 Canon iPF8000 Canon iPF8000S

	Canon iPF8100 Canon iFP8300 Canon iPF8300S Canon iPF8310 Canon iPF8310S Canon iPF8400 Canon iPF8400S Canon iPF8400SE Canon iPF8410S Canon iPF8410SE Canon iPF9000 Canon iPF9000S Canon iPF9100 Canon iPF9400 Canon iPF9400S Qualified with Plain Paper and Coated Paper only.
Canon W	Canon W6200PG Canon W6400D Canon W6400PG Canon W7200 Canon W8200 Canon W8200PG Canon W8400 Canon W8400D Canon W8400PG
Canon PRO	Canon PRO-500 Canon PRO-520 Canon PRO-540 Canon PRO-540S Canon PRO-560S Canon PRO-1000 Canon PRO-2000 Canon PRO-4000 Canon PRO-4000S Canon PRO-6000 Canon PRO-6000S
Canon TM	Canon TM-200 Canon TM-205 Canon TM-300 Canon TM-305 Canon TM-5200 Canon TM-5205 Canon TM-5300 Canon TM-5305
Canon TX	Canon TX-2000 Canon TX-3000 Canon TX-4000 Canon TX-5200 Canon TX-5300 Canon TX-5400
Encad NovaJet	Encad NovaJet 500 Encad NovaJet 630 Encad NovaJet 700 Encad NovaJet 750 Encad NovaJet 850 Encad NovaJet 1000i Encad NovaJet PRO Encad NovaJet PROe Encad NovaJet PRO 600e
Epson Stylus Pro	Epson Stylus Pro 4400 Epson Stylus Pro 4800 Epson Stylus Pro 7000 Epson Stylus Pro 7400 Epson Stylus Pro 7600 Epson Stylus Pro 7700

	Epson Stylus Pro 7710 Epson Stylus Pro 7800 Epson Stylus Pro 7880 Epson Stylus Pro 7880C Epson Stylus Pro 7890 Epson Stylus Pro 7900 Epson Stylus Pro 7910 Epson Stylus Pro 9000 Epson Stylus Pro 9400 Epson Stylus Pro 9600 Epson Stylus Pro 9700 Epson Stylus Pro 9710 Epson Stylus Pro 9800 Epson Stylus Pro 9880 Epson Stylus Pro 9880C Epson Stylus Pro 9890 Epson Stylus Pro 9900 Epson Stylus Pro 9910 Epson Stylus Pro 10000 Epson Stylus Pro 10600 Epson Stylus Pro 11880 Epson Stylus Pro 11880C
Epson SureColor P	• Epson SureColor SC-P6000 • Epson SureColor SC-P7000 • Epson SureColor SC-P8000 • Epson SureColor SC-P9000
Epson SureColor T	Epson SureColor SC-T3000 Epson SureColor SC-T3050 Epson SureColor SC-T3070 Epson SureColor SC-T3080 Epson SureColor SC-T3200 Epson SureColor SC-T3200D Epson SureColor SC-T3250 Epson SureColor SC-T3250D Epson SureColor SC-T3270 Epson SureColor SC-T3270D Epson SureColor SC-T3400 Epson SureColor SC-T3450 Epson SureColor SC-T3470 Epson SureColor SC-T3480 Epson SureColor SC-T5000 Epson SureColor SC-T5050 Epson SureColor SC-T5070 Epson SureColor SC-T5080 Epson SureColor SC-T5100 Epson SureColor SC-T5150 Epson SureColor SC-T5170 Epson SureColor SC-T5180 Epson SureColor SC-T5200 Epson SureColor SC-T5200D Epson SureColor SC-T5250 Epson SureColor SC-T5250D Epson SureColor SC-T5270 Epson SureColor SC-T5270D Epson SureColor SC-T5400 Epson SureColor SC-T5450 Epson SureColor SC-T5470 Epson SureColor SC-T5480 Epson SureColor SC-T7000 Epson SureColor SC-T7050 Epson SureColor SC-T7070 Epson SureColor SC-T7080 Epson SureColor SC-T7200 Epson SureColor SC-T7200D Epson SureColor SC-T7250 Epson SureColor SC-T7250D Epson SureColor SC-T7270 Epson SureColor SC-T7270D

Gestetner	Gestetner GWD2004 Gestetner GWD2006 Gestetner MP W7100 PS Gestetner MP W8140 PS Gestetner SP W2470
HP DesignJet	HP DesignJet 70 HP DesignJet 90 HP DesignJet 110 HP DesignJet 111 HP DesignJet 120 HP DesignJet 130 HP DesignJet 500 (HP-GL/2) HP DesignJet 500PS (HP-GL/2) HP DesignJet 510 (HP-GL/2) HP DesignJet 510PS (HP-GL/2) HP DesignJet 750C HP DesignJet 800 HP DesignJet 800PS HP DesignJet 1050C HP DesignJet 1055CM HP DesignJet 2000CP HP DesignJet 2500CP HP DesignJet 3000CP HP DesignJet 3500CP HP DesignJet 4000 HP DesignJet 4000ps HP DesignJet 4020 HP DesignJet 4020ps HP DesignJet 4500 HP DesignJet 4500mfp HP DesignJet 4500ps HP DesignJet 4520 HP DesignJet 4520mfp HP DesignJet 4520ps HP DesignJet 5000 HP DesignJet 5000PS HP DesignJet 5100 HP DesignJet 5100PS HP DesignJet 5500 HP DesignJet 5500PS
HP DesignJet D	HP DesignJet D5800 HP DesignJet D5800PS
HP DesignJet T	HP DesignJet T120 HP DesignJet T520 24in HP DesignJet T520 36in HP DesignJet T610 HP DesignJet T610ps HP DesignJet T620 HP DesignJet T620ps HP DesignJet T730 HP DesignJet T770 HP DesignJet T770ps HP DesignJet T770 24 HP DesignJet T770ps 24 HP DesignJet T790 HP DesignJet T790ps HP DesignJet T795 HP DesignJet T795ps HP DesignJet T830 MFP HP DesignJet T920 HP DesignJet T920ps HP DesignJet T930 HP DesignJet T930ps HP DesignJet T1100 HP DesignJet T1100ps HP DesignJet T1120

	HP DesignJet T1120mfp HP DesignJet T1120ps HP DesignJet T1200 HP DesignJet T1200ps HP DesignJet T1300 HP DesignJet T1300ps HP DesignJet T1500 HP DesignJet T1500ps HP DesignJet T1530 HP DesignJet T1530ps HP DesignJet T1600 HP DesignJet T1600dr HP DesignJet T1700 HP DesignJet T1700 ps HP DesignJet T1700dr HP DesignJet T1700dr ps HP DesignJet T1708 HP DesignJet T1708 ps HP DesignJet T1708dr HP DesignJet T1708dr ps HP DesignJet T2300 HP DesignJet T2300ps HP DesignJet T2500 HP DesignJet T2500ps HP DesignJet T2530 HP DesignJet T2530ps HP DesignJet T2600 HP DesignJet T2600dr HP DesignJet T3500 HP DesignJet T3500ps HP DesignJet T7100 HP DesignJet T7100ps HP DesignJet T7200 HP DesignJet T7200ps
HP DesignJet XL	HP DesignJet XL 3600
HP DesignJet Z	HP DesignJet Z6 24in HP DesignJet Z6 44in HP DesignJet Z6dr 44in HP DesignJet Z9 24in HP DesignJet Z9 44in HP DesignJet Z9dr 44in HP DesignJet Z2100 HP DesignJet Z2110 HP DesignJet Z2600 HP DesignJet Z2600ps HP DesignJet Z3100 HP DesignJet Z3100ps HP DesignJet Z3200 HP DesignJet Z3200ps HP DesignJet Z5200 HP DesignJet Z5200ps HP DesignJet Z5400 HP DesignJet Z5400ps HP DesignJet Z5600 HP DesignJet Z5600ps HP DesignJet Z6100 HP DesignJet Z6100ps HP DesignJet Z6200 HP DesignJet Z6200ps HP DesignJet Z6600 HP DesignJet Z6600ps HP DesignJet Z6610 HP DesignJet Z6800 HP DesignJet Z6800ps HP DesignJet Z6810 42in HP DesignJet Z6810 60in

HP PageWide XL	HP PageWide XL 3900 HP PageWide XL 4000 HP PageWide XL 4000 MFP HP PageWide XL 4000PS HP PageWide XL 4000PS MFP HP PageWide XL 4100 HP PageWide XL 4500 HP PageWide XL 4500 MFP HP PageWide XL 4500PS HP PageWide XL 4500PS MFP HP PageWide XL 4600 HP PageWide XL 5000 HP PageWide XL 5000 Blueprinter HP PageWide XL 5000 MFP HP PageWide XL 5000PS HP PageWide XL 5000PS Blueprinter HP PageWide XL 5000PS MFP HP PageWide XL 5100 HP PageWide XL 5100 MFP Blueprinter HP PageWide XL 5100 MFP HP PageWide XL 5100PS HP PageWide XL 5100PS MFP Blueprinter HP PageWide XL 5100PS MFP HP PageWide XL 6000 HP PageWide XL 6000PS HP PageWide XL 8000 HP PageWide XL 8000 Blueprinter HP PageWide XL 8000PS HP PageWide XL 8000PS Blueprinter
Imagio	Imagio MP W3600 Imagio MP W2400
Lanier	Lanier LP124w Lanier LW324 Lanier LW326 Lanier MP W7100 PS LANIER MP W8140 PS
Mutoh	Mutoh RJ-900C Mutoh RJ-900X Mutoh RJ-901C Mutoh RJ-901X Mutoh RJ-4000 Mutoh RJ-4100 Mutoh RJ-8000
NRG	NRG MP W2400 NRG MP W3600 NRG MP W7100 PS NRG MP W8140 PS NRG SP W2470
Océ 535	Océ 535X-42 Océ 535X-60 Océ 535X-600-42 Océ 535X-600-60
Océ ColorWave	Océ ColorWave 300 Océ ColorWave 500 Océ ColorWave 550 Océ ColorWave 600 Océ ColorWave 650 Océ ColorWave 700 Océ ColorWave 810 Océ ColorWave 900 Océ ColorWave 910 Océ ColorWave 3500 Océ ColorWave 3700 Océ ColorWave 9000
Océ CS	Océ CS5050

	Océ CS5070
Océ PlotWave	Océ PlotWave 300 Océ PlotWave 340 Océ PlotWave 345 Océ PlotWave 350 Océ PlotWave 360 Océ PlotWave 365 Océ PlotWave 450 Océ PlotWave 500 Océ PlotWave 550 Océ PlotWave 750 Océ PlotWave 900
Océ TCS	Océ TCS300 Océ TCS400 Océ TCS500
Océ TDS	Océ TDS300 Océ TDS320 Océ TDS400 Océ TDS450 Océ TDS600 Océ TDS700 Océ TDS750 Océ TDS800 Océ TDS860
Ricoh	Ricoh Aficio MP W2400 Ricoh Aficio MP W3600 Ricoh Aficio SP W2470 Ricoh CW2201SP Ricoh W6700SP Ricoh W7100 PS Ricoh W8140 PS
Roland	Roland Hi-Fi JET FJ-40 Roland Hi-Fi JET FJ-50 Roland Hi-Fi JET FJ-540 Roland Hi-Fi JET FJ-740
Savin	Savin 2404WD Savin 2404WDP Savin 2406WD Savin MP W7100 PS Savin MP W8140 PS
Seiko	Seiko LP-1010
Selex	Selex SG-950T
Xerox	Xerox 6204 Xerox 8825 Xerox 8830