

# MEASURE TEMPLATE FOR QUICK-RELEASE AXLES

**CROOZER**

HOLD THE QUICK-RELEASE AXLE TO THIS TEMPLATE TO MEASURE THE LENGTH

