


CALIBRATING DGT PEGASUS


1

TURN OFF BOARD
AND REMOVE PIECES



2

HOLD ON/OFF BUTTON FOR 10 SECONDS,
UNTIL THE BOARD STOPS FLASHING



3

PLACE PIECES AND PLAY!

