



VT2000 LEDS & BUZZER SPECIFICATION

- BLUE LED (RECORD) ●
- GREEN LED (COMMUNICATION) ●
- FRONT LED
- Buzzer



Status/Step	LED			Front LED	Buzzer	
	Record	Communication				
	Blue	Green				
						
Start-up	Booting step1		On	Off	On	
	Booting step2		On and Off		Off	
	Booting Finished		On		Off	「beep」(1time)
Power off	Power off		Simultaneous Flashing (Blink rate: fast)		Off	
Record	Continuous Record	Recording	Flashing (Blink rate: Slow)		Off	
	Event Record	Stand by	Flashing (Blink rate: Very Slow)		Off	
		recording	Flashing (Blink rate: fast)		Off	
	Dual Record	Continuous Recording	Flashing (Blink rate: Slow)		Off	
		Event recording	Flashing (Blink rate: fast)		Off	
Communication	3G Network Device Ready			On		
	Communication			Flashing (Blink rate: fast)		
Function	SD Format		Simultaneous Flashing (Blink rate: normal)		Off	(Beep, 1time) and then repeat
	G-Sensor Calibration					「Beep→(3seconds later) Be, BeBeep」
	FW Upgrade		On and Off	Off and On	Off	
Warning	SD Card	SD Card Full	Flashing (Blink rate: Slow) 3times, and off 3seond. And then repeat		Off	「BeepBeepBeepBeep」 (3times)
		without setting file	Simultaneous Flashing (Blink rate: Normal) 4seconds and then repeat it every minute.			
Error	Record Error	No SD, SD error, SD Lock, Write fail, No folder	Simultaneous Flashing (Blink rate: Slow)			「BeepBeepBeepBeep」 (3times)
	Communication Error	3G Network Device error		Off		「BeepBeep」 (3times)
		Data Network connection error		Off		
		DMS communication error		Flashing (Blink rate: Slow)		
Event Trigger	G-Sensor, Rec Button, Alarm-In					「DingDong, DingDong」 (1time)
	Over Speed					「Be, Beep, Be, Beep」(1time)



t +44 (0) 1246 225 745
e info@visiontrack.com
w visiontrack.com
s support.visiontrack.com