


Fail secure releases (AC or DC) can be connected directly to the entry panel.
 The entry panel also provides a volt free output (C, NO, NC) for interfacing to third party products.
 If using a fail safe release or maglock see PAGE2.

Urmet Communication & Security UK Ltd Urban Hive, Avenue West Skyline 120 Great Notley Essex CM77 7AA Tel 01376 556010 Fax 01376 567874 www.urmet.co.uk	Title	2Voice video entry system schematic wiring details			
	Drawing No.	UD06466	PAGE1		
	Date	8-12-2016	Drawn by	TC	Checked LK
	Revision	01			



Urmet Communication & Security UK Ltd Urban Hive, Avenue West Skyline 120 Great Notley Essex CM77 7AA Tel 01376 556010 Fax 01376 567874 www.urmet.co.uk	Title	2Voice video entry system schematic wiring details				
	Drawing No.	UD06466	PAGE2			
	Date	8-12-2016	Drawn by	TC	Checked	LK
	Revision	01				