



### **WARNING - risk of burning!**

- ⇒ The barbecue must be positioned on a stable and secure surface when it is in use, otherwise it may tip over.
- ⇒ **WARNING!** This barbecue becomes very hot and should not be moved while in use!
- ⇒ Wear barbecue mitts or use barbecue tongs when barbecuing .
- ⇒ Allow the barbecue to cool down completely before cleaning it.
- ⇒ **CAUTION!** Do not use spirit or petrol to light or re-light the fire!

⇒ **CAUTION!** Only use firelighters that correspond to the European Standard for firelighters (EN 1860-3)!

⇒ Never use water to extinguish the charcoal.



### **WARNING - risk of suffocation!**

⇒ Do not use indoors!



### **DANGER to children and pets!**

⇒ Never leave the hot barbecue unattended.

⇒ **WARNING!** Keep children and pets at a safe distance!

## Safe Operation of the Barbecue

**Before using the barbecue for the first time, it should be heated with fuel (charcoal or briquette) for approximately 30 minutes.**

## General hints for a successful assembly

Carefully read the assembly instructions and the listed safety hints. Take time to assemble the barbecue and allow for a free area of approximately two - three square metres. Remove the barbecue from the packaging!

**Note:** First assemble all parts loosely, upon completion tighten all nuts and bolts securely

## Single part list

A.	Cooking Grill	2
B.	Grill Handle	4
C.	Wind shield, side	2
D.	Wind shield, back	1
E.	Grill Support	1
F.	Grill Support, centre	1
G.	Charcoal Tray	2
H.	Hearth	1
I.	Carrying Handle	1
J.	Long Leg	1
K.	Wheel Leg	1
L.	Connecting Tube	2
M.	Bottom Wire Tray	1
N.	Leg Cap (pre assembled)	2
O.	Wheel	2
P.	Feet for Charcoal tray	4

## Preparation

Check that all parts are complete as per the list and drawing. Have suitable tools ready.

