

Water Polo Ball Release

The ball release is used for the start of play of water polo matches.

Retained on the half distance line, the ball is put into play when the ball release is submerged by pulling the rope from the side of the pool, allowing for fair and accurate starts every time.

At the start of play as the swimmers approach the ball, the ring is pulled under water and the ball released.

Unique qualities:

- Official FINA
- Fits men, women and junior size Water Polo balls
- Easy to install
- Easy to use



Product description:

EVA foam, high density plastic and stainless steel
 Float made from high density plastic and EVA-foam
 25 m retainer cord equipped with snap hokks for ease of installation



Selected When it Counts

Technical information



In order to use (sold separately)

- Two eyebolts need to be installed at the bottom of the pool
- One pool deck anchor is needed



Associated products



1512001 Water Polo Balls
 Herrer W6000, W6000C, W6000W
 Damer W6009, W6009C, W6009W
 Junior
 Mini

Our goal is 100%
 customer
 satisfaction

Malmsten – swimming hall specialists with over 40 years
 experience in the development of swimming pool equipment.
 Explore the full product range at www.malmsten.com

Selected When it Counts