



## Advertising structure for aquatic use

### For water polo field of play; diving or synchronized swimming partition

Advertising structure in 4 parts, each 9,9m, inflatable and perfect for aquatic use.

Place for advertising banners on front and back.

Easy affixing of advertising banners (not included) on pre-sawn velcro.

Arrives with electric pump and may be transported easily.

#### Unique qualities:

- Strong plastic-treated trevira material
- With Velcro front for banner placement
- Easy inflated and deflated
- Comes in bags for storage and protection



#### Product description:

Material: Strong plastic-treated trevira material

Dimensions: 4 x 9,9 m (Length), Base: 1650mm, Height: 1000 mm

Information: Sold Per Set (4 units) Including one electric pump.

#### Important:

Electric pump is required – attention to not to use electric pump near water.

Usage instructions have to be followed, valves may not be opened. Air is pumped in or sucked out using the pump.



*Selected When it Counts*



## Advertising structure for aquatic use

### Useful information

- Advertising inflatable structure consisting of 4 units 9,9m x 1,65 x 1 m. With place for approximately 6, 12 or 18 banners the width of 0,7 m per structure.
- Be careful when opening storage boxes and handling the equipment. A cutting knife, sharp corners or dragging on pool deck may damage the unit.
- To inflate or deflate use pump and do while equipment is out of water.
- To inflate: 1. Close the zipper. 2. Unscrew the plug. 3. Push in the valve. 4. Place pump and blow in air. It should normally take about 30minutes for 1 structure. 5. When finished - screw back the plug.
- Place advertisement banners while inflated. It is possible to place two in front and one on the back.
- Place inflatable structure in pool water. You may attach with rope to pool deck, or use the suction plugs (8 units are included).
- When finished using - carefully remove from pool. Attention to that any sharp edge may damage the PVC. Rinse with clean water and let dry.
- When fully dried - deflate units.
- To deflate: 1. Open the zipper. 2. Unscrew the plug. 3. Use the "air-intake" side on the pump.
- To fit back into storage box it is crucial to tightly roll and fold the structure.
- Important - never touch the safety valves! These are used to automatically deflate unit when need be.
- In case of air leakage through a small hole - wipe area dry and affix repair sheet (included) with suitable glue for PVC (not included).
- Banners: approximately 6, 12 or 18 banners (per 20m structure) of 0,7 m width should be made with male 5cm Velcro straps on top and bottom. Attention: The Velcro on the inflatable structure is female.