



PRODUCT INFORMATION

EVO®

ESPRESSO MACHINE CLEANING POWDER

HIGH PERFORMANCE

With its rapidly soluble and free-rinsing formulation, EVO® cleans like no other espresso machine cleaner. Coffee oils, grounds and stains are removed, improving the taste and aroma of espresso after the machine is cleaned. EVO® also leaves no trace of odour.

CERTIFIED FOR ORGANIC USE

EVO® is registered by Australian Certified Organic (ACO) as an allowed input in organic systems. EVO® is free from phosphate and GMOs.

SAFE FOR YOU AND YOUR MACHINE

Safe for all machine parts, EVO® is listed with NSF. It has been tested, evaluated and passed the most stringent toxicology and corrosivity standards. The ingredients and formulation of the products that are NSF certified are safe, leave no harmful residues and do not cause corrosion within the coffee machine.

RAPIDLY BIODEGRADABLE

All EVO® ingredients are rapidly biodegradable meeting international standards.

ECONOMICAL

Only the smallest amount of EVO® is needed for a superior clean. A measuring scoop is included in all jars for accurate dosing.

CERTIFICATIONS



NSF Protocol P152
Health Effects and Corrosivity
of Commercial Espresso
Machine Chemical Cleaners



Cafetto® is certified by independent globally recognised industry bodies



HOW TO USE - FILTERS AND GROUP HANDLES


- Soak group handles and filters in 500ml of hot water with 2 teaspoons of EVO® Espresso Machine Cleaner for 10 minutes. Rinse thoroughly in running hot water.

HOW TO USE - BACK FLUSH EACH DELIVERY GROUP

- Remove coffee filter from group handle, and replace with blind filter.
- For daily cleaning add 1 teaspoon of EVO® into the group handle and insert as if brewing espresso. If the machine is cleaned less often, use 2 teaspoons.
- Start cycle and allow to run for 10 seconds to dissolve cleaner. Stop cycle and allow to sit for 10 seconds.
- Start and stop cycle 4 more times - run for 10 seconds, stop for 10 seconds. Remove the group handle and rinse well under stream of water from delivery group. Turn off.
- Re-insert handle with blind filter, start and stop cycle 10 times - run for 5 seconds, stop for 2 seconds to ensure thorough rinsing. Remove blind filter and insert regular filter. Brew and discard a single espresso to re-season machine.

HOW TO USE

EVO® is a registered trademark of Cafetto Pty Ltd.



| PRODUCT NAME | TYPE OF UNIT PACK | NET WEIGHT | # OF UNITS PER CASE | PRODUCT CODE / BARCODE | PRODUCT CODE / CARTON |
|--------------|-------------------|------------|---------------------|------------------------|-----------------------|
| EVO® | 25g Sachet | 1.1kg | 12 | 9345941104761 | E10833 |
| | 500g Jar | 6kg | 12 | 9345941290150 | E29160 |
| | 1kg Jar | 12kg | 12 | 9345941290105 | E29120 |