



Snowtalk Quick Start Guide



Button Operation

- Tap Tapping
- 1" Press for 1 sec
- Double Tapping
- 3" 5" Press and Hold


Power On/Off




Configuration Menu




Battery Check




Volume Adjust



Bluetooth Pairing Phone, MP3



Music



Mobile Phone



Answer



End



Reject



Voice Dial




Redial




Note:
Voice Dial and Redial functions are available only in stand-by mode and not available during music playback.

Headset Pairing Intercom




Multiple Headset Pairing Intercom


Last Come, First Served




Start Intercom



Tap



Double Tap



Triple Tap

End Intercom



Use of the product at a high volume for a long period of time may damage your eardrums or hearing ability. Keep the volume at a modest level.

A full version of the manual is downloadable at www.sena.com.

SENA

Sena Technologies, Inc.

www.sena.com

Customer Support: support.sena.com

Tel: 408-300-9797 | E-mail: support@sena.com