

# Wide Format Scanning and Copying Software

## Contents

[Version Changes](#)

[Supported Operating Systems](#)

[Supported Printers](#)

## Version Changes

Changes in version 1.2.1		
APEV-636	Fix	Printing an opened file sometimes resulted in wrong colors
APEV-651	Fix	Sometimes no image was shown after scanning or opening a file
APEV-669	Fix	Using 'Save and Scan' only resulted in saving file, not starting a new scan
	Fix	Various minor GUI improvements
Changes in version 1.2		
APEV-296	New	Accuracy Lens Enhancement (ALE) option added to 'INPUT SIZE' panel
APEV-368	New	<ol style="list-style-type: none"><li>1. 'Default position' option in 'POSITION' panel under 'Table' Allows user to customize table placement when not scanning</li><li>2. "To Center" and "To Right" buttons in 'POSITION' panel under 'Table' Automatically moves table to center or rightmost position</li></ol>
APEV-455	New	'AUTO' adjustment button in 'POSITION' panel under 'Scan module' Does an automatic adjustment of scan module's height based on selected lasers
APEV-564	New	'QUALITY' panel changed and now contains: <ol style="list-style-type: none"><li>1. 'Optimize for' option 'Speed (8/16-bit)' is similar scanning with previous version 'Quality (16/48-bit)' option reduces noise at the expense of scanning speed</li><li>2. 'Exposures per line' Reduces noise even further at the expense of scanning speed</li><li>3. 'Save as 16/48-bit' (also present in 'OUTPUT FILE' panel)</li></ol>
APEV-576	New	"Crop+" and "Crop-" buttons in viewer interactions Pressing slightly enlarge/reduce selected image area

APEV-402	Fix	It was possible clicking 'STOP SCANNING' button before image data was received, causing various issues
APEV-439	Fix	Opened image had wrong colors
APEV-440	Fix	It was possible clicking Scan button while scanning or during table movement, causing various issues
APEV-469	Fix	Scanning to non-existing location caused program to crash
	Fix	Various GUI and stability improvements
APEV-613	New	Support for new printers added (Canon, Epson, HP) See: <a href="#">Supported Printers</a>
WID-303	Fix	Scanning process could sometimes freeze

## Changes in version 1.1.5

APEV-429	New	Table alignment now calibrates start of scan to match print on table
WID-243	Fix	Height measurement would not work well if the scan module was moved too high
APEV-530	Fix	Stitch sometimes didn't work well on some glossy materials
APEV-498 WID-240	Fix	Improvement of camera stitching when scanning objects with blind corners such as boxes, picture frames, etc.

## Changes in version 1.1.4

WID-222	Fix	Stitch sometimes didn't function well on dark materials
WID-223	Fix	Color matching could produce horizontal bands
WID-224	Fix	The first couple of lines could contain wrong data
WID-227	Fix	Scanning in lower resolutions sometimes produced weak vertical bands in dark areas
WID-229	Fix	Sometimes the application didn't wake the scanner

## Changes in version 1.1.3

WID-216	Fix	Scanning structured materials in camera overlap, especially with 3D effect, sometimes created visible artefacts between cameras
---------	-----	---

## Changes in version 1.1.2

APEV-414	Fix	Improved stitch and alignment calibration
----------	-----	---

WID-209	Fix	Improved color matching between cameras
<b>Changes in version 1.1.1</b>		
APEV-369	New	Add mechanical only calibration
APEV-414	Fix	Improved stitch and alignment calibration
<b>Changes in version 1.1</b>		
APEV-304	New	Restore existing file if cancelling Save
APEV-376	Fix	Improved software speed
APEV-379	Fix	Slider, especially the '3D EFFECT' slider, could be hard to use. The touch area has been increased for all sliders
APEV-380	Fix	When pressing the alignment button, the alignment line was sometimes placed outside viewed area
APEV-384	Fix	Using 'ROTATE' with 'Indexed color' caused wrong colors
APEV-385	Fix	Using 'FLIP' changed viewed area
APEV-387	Fix	Error message during calibration sometimes went outside screen
APEV-414	Fix	Improved stitch and alignment calibration
WID-209	Fix	On some originals you could see color differences between cameras
	Fix	Improved calibration quality and stability
<b>Changes in version 1.0.1</b>		
APEV-366 APEV-372	New	Portuguese and Turkish added
APEV-300	Fix	Selecting WPS PDF printer caused error
APEV-303	Fix	Pressing scan button while table was moving resulted in error
APEV-306	Fix	Using auto size with rotation or mirror selected wrong area of scan
APEV-309	Fix	Scanning CLC sheet sometimes failed even though sheet was placed correctly
APEV-310	Fix	Scanning CLC caused currently open image to close

APEV-315	Fix	Cancelling while sending email did not work
APEV-316	Fix	Changing 'Paper source' on some printers caused flickering and did not work
APEV-320	Fix	Opening 'POSITION' panel caused currently open image to close
APEV-322	Fix	Opening program sometimes gave errors during 'SCANNER SEARCH'
APEV-339 WID-196	Fix	Opening 'POSITION' panel sometimes did not show focus info After that program required restart to work properly
APEV-347	Fix	Pressing 'Finish scan' immediately after pressing Scan button sometimes had no effect
APEV-366	Fix	Installation did not ask for wanted language
WID-173	Fix	Sometimes operation resulted in 'Scanner cable error'
	Fix	Various improvements to calibration
<b>Changes in version 1.0</b>		
	New	Initial version

## Supported Operating Systems

- Windows 10 (Enterprise) 64-bit
- Windows 11 (Enterprise) 64-bit