

# Wide Format Scanning and Copying Software

## Contents

[Version Changes](#)

[Supported Operating Systems](#)

[Supported Printers](#)

## Version Changes

<b>Changes in version 1.2.4</b>		
APEV-783 APEV-788	New	Predefined and user presets are now separated in the GUI
APEV-706	New	Default colour management profile changed to AdobeRGB
APEV-747	New	Addition of ProPhoto RGB color space
APEV-735	New	Full and mechanical calibration now calibrate lasers
APEV-736 APEV-762 APEV-765	New	Addition of Moire Reduction
APEV-704	New	Now possible to choose Front or Back object placement
APEV-719 APEV-727 APEV-728 APEV-733 APEV-734 APEV-776	New	Creation of diagnostic package added
APEV-781	Fix	Changes in GUI to help the user choose the correct settings
APEV-706 APEV-	Fix	Changed and additional presets

760 APEV-780		
APEV-723 APEV-737 APEV-747 APEV-748	Fix	New ICC profiles
WID-436	Fix	Stitch improvements
WID-445 WID-442	Fix	Color matching improvements
APEV-716 WID-441 APEV-740	Fix	Improved scanner calibration
APEV-656	Fix	Changing language in UI would sometimes not work
APEV-739	Fix	Viewing at 100% could make a good scan look bad
APEV-769	Fix	Scanner IP-address was not always updated correctly
APEV-711 APEV-684 APEV-715 APEV-712	Fix	Improved Support Package
APEV-702 APEV-732	Fix	Service: test 109 would show unexpected pop-up at end
APEV-709	New	Service: test 9, add option to export .con files
APEV-795	Fix	Service: Table Alignment could sometimes fail
APEV-735 APEV-731	New	Service: Improved Check Laser test
APEV-790	Fix	Service: Add date to logfiles when opening scanner

## Changes in version 1.2.3

WID-433	Fix	Calibration could fail when using restricted user
WID-238	Fix	Table alignment could fail when using restricted user

## Changes in version 1.2.2

APEV-694	Fix	Too often the height measurement in POSITION panel did not show any info for one or more lasers. If this happened under Auto height adjustment, the adjustment would never finish.
APEV-699	Fix	Service: test 9, camera centering was always zero
APEV-698	Fix	Service: S107 check laser test, could only be run in up-up lamp positions

## Changes in version 1.2.1

APEV-636	Fix	Printing an opened file sometimes resulted in wrong colors
APEV-651	Fix	Sometimes no image was shown after scanning or opening a file
APEV-669	Fix	Using 'Save and Scan' only resulted in saving file, not starting a new scan
	Fix	Various minor GUI improvements

## Changes in version 1.2

APEV-296	New	Accuracy Lens Enhancement (ALE) option added to 'INPUT SIZE' panel
APEV-368	New	<ol style="list-style-type: none"><li>'Default position' option in 'POSITION' panel under 'Table' Allows user to customize table placement when not scanning</li><li>"To Center" and "To Right" buttons in 'POSITION' panel under 'Table' Automatically moves table to center or rightmost position</li></ol>
APEV-455	New	'AUTO' adjustment button in 'POSITION' panel under 'Scan module' Does an automatic adjustment of scan module's height based on selected lasers
APEV-564	New	'QUALITY' panel changed and now contains: <ol style="list-style-type: none"><li>'Optimize for' option 'Speed (8/16-bit)' is similar scanning with previous version 'Quality (16/48-bit)' option reduces noise at the expense of scanning speed</li><li>'Exposures per line' Reduces noise even further at the expense of scanning speed</li><li>'Save as 16/48-bit' (also present in 'OUTPUT FILE' panel)</li></ol>
APEV-576	New	"Crop+" and "Crop-" buttons in viewer interactions Pressing slightly enlarge/reduce selected image area
APEV-402	Fix	It was possible clicking 'STOP SCANNING' button before image data was received, causing various issues
APEV-439	Fix	Opened image had wrong colors

APEV-440	Fix	It was possible clicking Scan button while scanning or during table movement, causing various issues
APEV-469	Fix	Scanning to non-existing location caused program to crash
	Fix	Various GUI and stability improvements
APEV-613	New	Support for new printers added (Canon, Epson, HP) See: <a href="#">Supported Printers</a>
WID-303	Fix	Scanning process could sometimes freeze

## Changes in version 1.1.5

APEV-429	New	Table alignment now calibrates start of scan to match print on table
WID-243	Fix	Height measurement would not work well if the scan module was moved too high
APEV-530	Fix	Stitch sometimes didn't work well on some glossy materials
APEV-498 WID-240	Fix	Improvement of camera stitching when scanning objects with blind corners such as boxes, picture frames, etc.

## Changes in version 1.1.4

WID-222	Fix	Stitch sometimes didn't function well on dark materials
WID-223	Fix	Color matching could produce horizontal bands
WID-224	Fix	The first couple of lines could contain wrong data
WID-227	Fix	Scanning in lower resolutions sometimes produced weak vertical bands in dark areas
WID-229	Fix	Sometimes the application didn't wake the scanner

## Changes in version 1.1.3

WID-216	Fix	Scanning structured materials in camera overlap, especially with 3D effect, sometimes created visible artefacts between cameras
---------	-----	---

## Changes in version 1.1.2

APEV-414	Fix	Improved stitch and alignment calibration
WID-209	Fix	Improved color matching between cameras

## Changes in version 1.1.1

APEV-369	New	Add mechanical only calibration
APEV-414	Fix	Improved stitch and alignment calibration

## Changes in version 1.1

APEV-304	New	Restore existing file if cancelling Save
APEV-376	Fix	Improved software speed
APEV-379	Fix	Slider, especially the '3D EFFECT' slider, could be hard to use. The touch area has been increased for all sliders
APEV-380	Fix	When pressing the alignment button, the alignment line was sometimes placed outside viewed area
APEV-384	Fix	Using 'ROTATE' with 'Indexed color' caused wrong colors
APEV-385	Fix	Using 'FLIP' changed viewed area
APEV-387	Fix	Error message during calibration sometimes went outside screen
APEV-414	Fix	Improved stitch and alignment calibration
WID-209	Fix	On some originals you could see color differences between cameras
	Fix	Improved calibration quality and stability

## Changes in version 1.0.1

APEV-366 APEV-372	New	Portuguese and Turkish added
APEV-300	Fix	Selecting WPS PDF printer caused error
APEV-303	Fix	Pressing scan button while table was moving resulted in error
APEV-306	Fix	Using auto size with rotation or mirror selected wrong area of scan
APEV-309	Fix	Scanning CLC sheet sometimes failed even though sheet was placed correctly
APEV-310	Fix	Scanning CLC caused currently open image to close
APEV-315	Fix	Cancelling while sending email did not work
APEV-316	Fix	Changing 'Paper source' on some printers caused flickering and did not work
APEV-320	Fix	Opening 'POSITION' panel caused currently open image to close
APEV-322	Fix	Opening program sometimes gave errors during 'SCANNER SEARCH'
APEV-339	Fix	Opening 'POSITION' panel sometimes did not show focus info After that program required restart to work properly

WID-196		
APEV-347	Fix	Pressing 'Finish scan' immediately after pressing Scan button sometimes had no effect
APEV-366	Fix	Installation did not ask for wanted language
WID-173	Fix	Sometimes operation resulted in 'Scanner cable error'
	Fix	Various improvements to calibration
<b>Changes in version 1.0</b>		
	New	Initial version

## Supported Operating Systems

- Windows 10 (Enterprise) 64-bit
- Windows 11 (Enterprise) 64-bit